


Remove the lenses

拆卸透镜


01

Loosen the screw.
松开限位螺丝



02

Pinch the edge of the lens holder, rotate the lens and remove it.
捏住透镜支架边缘,旋转透镜并取下。




Installing the lenses

安装透镜

01


Install the lens on the barrel according to left and right; press the edge of the lens bracket.
将要更换的透镜根据左右分别安装在镜筒上；按压透镜支架边缘。



※ **Reminder** : Each set of lenses has a left & right-side lens.
提醒： 每套镜片都有左右两侧的镜片。

02

After ensuring that the lens and the barrel's position matches, lock the screw.
确保安装位置吻合后，锁紧限位螺丝。



Download software

APP下载与设备绑定



For guidance on how to bind the Crystal with your computer, follow the instructions inside the software.

扫描下方二维码下载APP，设备绑定指南请进入APP查看。

Software features

APP 功能

- 1. Store - Provides paid and free games and applications.
- 2. Device pairing - account, WIFI, and screen.
- 3. Product manual, product introduction.
- 4. After-sales service link.

- 1. 内容商店——提供收费及免费的游戏应用。
- 2. 设备绑定——设定账户&WiFi及投屏功能。
- 3. 产品说明书、产品介绍。
- 4. 售后服务链接。

For more guidance, please: pimax.com/support

更多指导内容，请至网站查看：
pimax.com/support

Pimax Crystal


Quick Guide

Connect to PC

PC模式连接

1. Connect the power adapter to the USB-HUB.
2. Connect the DP cable. Put two USB plugs into the USB-HUB, and the DP cable into the computer.
3. Connect the USB-HUB to the PC. Use the separate USB to USB cable.
4. Connect the DP cable to the headset.

1. USB-HUB连接电源适配器。
2. DP线缆USB接口连接USB-HUB、DP接口连接PC。
3. USB-HUB连接PC。
4. 头显DP线连接头显。



Battery Installation/Replacement

电池安装/更换

Battery Installation

电池安装

Hold the buttons on both sides of the battery, and push the battery into the helmet in the direction of the arrows.

按住电池两边的按钮，按照箭头方向，将电池推入头盔。


Battery Replacement

更换电池

Push the battery free from the latch on one side, then push it free from the latch on the other side. For specific instructions, please scan the QR code to watch the video.

请先取下电池一侧卡扣，再取下另一侧卡扣。具体操作可查看视频。

Youtube:
<https://youtu.be/pQs9TyS3LZE>




How to hot-swap the battery

如何使用电池的热插拔功能

1. Please perform the battery hot-swap after the device enters low-power mode.
2. Press the power button to turn off the screen and wait for the blue light at the battery compartment to turn off (at the back of the headset).
3. Please Replace the battery within 1 minute.

1. 热插拔电池功能请在设备进入低功耗模式后进行。
2. 按电源键关闭屏幕，并等待电池仓位置的蓝灯关闭。
3. 请在1分钟内完成电池更换。




PC / AIO mode

切换PC/一体机模式

Toggle the switch to select 'PC' mode or 'AIO' mode (Standalone) .

拨动开关，选择要使用「PC」模式或者「一体机」模式。



※ **Reminder :** If the device is turned on, the headset will automatically restart if you switch modes.
提醒: 开机状态下切换，头显会自动重启。